

# Chain Link Door Screen



## Fitting Instructions

[www.flydor.co.uk](http://www.flydor.co.uk)

**t: 01603 897 799 e: [sales@flydor.co.uk](mailto:sales@flydor.co.uk)**





## CHAIN LINK DOOR SCREEN

Please find supplied face fitting brackets as shown.



Affix directly to frame with suitable screws. Leave enough room (20mm) above bracket to allow the screen to be lifted out when not in use.



Simply lift and hook headrail unto brackets. Adjust Headrail to desired position by sliding back and forth.



Finished Screen.

*Please ensure that chains are at least 20mm off floor to allow free flow movement.*

